

## **C868 – Software Capstone Project Summary**

### **Task 2 – Section C**



**Capstone Proposal Project Name:** Tool Calibration Log

**Student Name:** \_\_\_\_\_

Table of Contents**Table of Contents**

<i>Table of Contents.....</i>	<i>2</i>
<i>Task 2 Part C – C868 Software Development Capstone.....</i>	<i>4</i>
<i>Application Design and Testing .....</i>	<i>4</i>
<i>Design Document.....</i>	<i>4</i>
<b>Class Design.....</b>	<b>4</b>
<b>UI Design.....</b>	<b>5</b>
<i>Unit Test Plan.....</i>	<i>6</i>
<b>Introduction .....</b>	<b>6</b>
Purpose .....	6
Overview .....	7
<b>Test Plan .....</b>	<b>7</b>
Items .....	7
Features.....	7
Deliverables.....	7
Tasks.....	7
Needs .....	8
Pass/Fail Criteria .....	8
<b>Specifications.....</b>	<b>8</b>
<b>Procedures.....</b>	<b>8</b>
<b>Results .....</b>	<b>9</b>


<i>C4. Source Code.....</i>	<i>9</i>
<i>C5. Link to Live Version.....</i>	<i>9</i>
<i>Application Maintenance Guide .....</i>	<i>10</i>
<b>Installation and Debugging of the Application.....</b>	<b>10</b>
Prerequisites:.....	10
Installation:.....	10
<i>User Guide.....</i>	<i>11</i>
<b>Introduction .....</b>	<b>11</b>
<b>Login Steps.....</b>	<b>11</b>
<b>Navigating the Main Menu .....</b>	<b>11</b>
Navigation Bar.....	12
Table View .....	12
<b>Managing Users .....</b>	<b>13</b>
<b>Managing User Groups.....</b>	<b>14</b>
<b>Managing Departments .....</b>	<b>15</b>
<b>Managing Facilities .....</b>	<b>15</b>
<b>Managing Tool Types.....</b>	<b>16</b>
<b>Managing Tools .....</b>	<b>16</b>
<b>Entering Calibration Logs Add/Edit Calibration Logs.....</b>	<b>17</b>
<b>Reports .....</b>	<b>18</b>

## Task 2 Part C – C868 Software Development Capstone

**Application Design and Testing****Design Document****Class Design**


Below is a UML diagram of the classes responsible for creating the secure login, security groups, and filtering by site required by WWS. The LoginController class contains the method isValidUser which is triggered upon Username and Password submission. This method makes a call to the method getSHA256 within the ViewModel class where the password string is hashed using the SHA256 algorithm before being queried in the database.

Upon validation, setCurrentUser is called from the User class and setCurrentFacility is called from the Facility class. The MainMenuController makes features of the application accessible depending on the User Group assigned to that currentUser. As the desired feature is selected, the getCurrentFacility method is used in the filter[model]ByFacility method of the ViewModel class. The tables are then populated with only relevant objects for their facility.




## UI Design

In the below images, Figure 1 demonstrates how the Login page looks to the user upon first opening the application. Figure 2 is the Main Menu screen that the user is greeted with when successfully logged in. This also shows the Calibration Log pane in view with data populated in the table.



The login screen is titled "Tool Calibration Log" and "Please Login". It features a "Username:" label with a text input field containing "admin", and a "Password:" label with a password input field showing eight dots. A "Submit" button is located at the bottom right.

Figure 1: High-Fidelity Login Screen



The main menu screen is titled "Main Menu" and "Calibrations Past Due!". It features a "Logout" button in the top right. On the left is a sidebar with buttons for "Calibration Logs", "Tools", "Tool Types", "Reports", "Users", "User Groups", "Department", and "Facilities". The "Calibration Logs" section is active, showing a table with the following data:

ID	Tool ID	Cal Date	Pass	Verified by
1	1/4" Torque Wrench   1234	2020-05-01	0	admin
2	3/8" Torque Wrench   3456	2020-04-29	1	admin
3	1/2" Torque Wrench   5567	2020-06-01	1	admin
4	Voltmeter   456	2020-06-07	1	admin
5	Voltmeter   6578	2020-05-01	0	admin

Below the table are "Edit Selected" and "Delete Selected" buttons. A "New Calibration" button and a search input field are also present.

Figure 2: High-Fidelity Main Menu Screen with Calibration Log Table Active

## Unit Test Plan

### Introduction

#### Purpose

During the login process it is vital to determine that the correct username and password is being used for comparison. The password is especially critical because it needs to be hashed correctly prior to comparison.

## **Overview**

In the LoginController class, the submit button triggers the isValidUser method which compares the username and password to all records from the user table in the database. The passwords are hashed using the SHA-256 algorithm, therefore, the isValidUser method calls ViewModel.getSHA256() to hash the password field prior to comparison.

## **Test Plan**

### **Items**

Two text fields within the LoginController class are used for username and password input. An ObservableList of User objects populated from the database is also used for validation by comparing the username and password properties for each User.

### **Features**

During the login process ViewModel.getSHA256() is called against the passwordTxt field value to generate the SHA-256 hash. A for loop is called to iterate through each User object in the ObservableList generated by ViewModel.getAllUsers(). Each user in the list calls getUserName() for comparison to the plaintext username input and getPassword() is compared to the password input hash value.

### **Deliverables**

The test produces console-based text output to show what information is produced from the text field compared to what information the ObservableList iterations produced.

### **Tasks**

To run the test the System.out calls in the isValidUser() method of the LoginController class must be uncommented. The application can then be run in Netbeans by hitting F6 and inputting user login info. Clicking submit triggers the test.

## Needs

Requirements for this test involves two primary applications:

1. Netbeans 8.2 is needed to conduct testing.
2. MySQL Workbench for inserting test user.
3. SHA256 Hash Generator (<https://passwordsgenerator.net/sha256-hash-generator/>) for validating hash.

## Pass/Fail Criteria

The result is considered a success when the output from the input fields matches the known username and password from the database.

## Specifications

Below is a screenshot of the test code. This method is contained within the LoginController class.

```
public boolean isValidUser() throws SQLException, NoSuchAlgorithmException {
    //ViewModel.buildUserList();
    String hashedPassword = ViewModel.getSHA256(passwordTxt.getText()).toUpperCase();
    System.out.println(userTxt.getText() + " | " + hashedPassword + " |");
    for (User user : ViewModel.getAllUsers()) {
        System.out.println(user.getUserName() + " | " + user.getPassword().toUpperCase());
        if (user.getUserName().equals(userTxt.getText())
            && user.getPassword().toUpperCase().equals(hashedPassword)) {
            User.setCurrentUser(userTxt.getText());
            Facility.setCurrentFacility(ViewModel.findDepartmentById(User.getCurrentUser().getDepartmentId()).getFacilityId());
            return true;
        }
    }
}
```

## Procedures

The procedures I used for performing this test are as follows:

1. Generated a SHA256 hash for the string "P@ssword".
2. Using MySQL Workbench, I connected to the database and created a new entry for the user table (username: hashTest, password: <hash from step 1>).
3. I uncommented the System.out calls from isValidUser().



4. Started the application and entered hashTest and P@ssword in the input fields, then hit submit.
5. Verified that the output on the top line matched the information returned from the database.

## Results

The results are output to the console to view what information was pulled from user input and what data was pulled from the database for comparison.

```
hashTest | 28EFB68DCBA507ECD182BEAD31E4E2D159B0F9185861D1EBFE60A12DFB310300
-----
admin | 19513FDC9DA4FB72A4A05EB66917548D3C90FF94D5419E1F2363EEA89DFEE1DD
jberry | 5E884898DA28047151D0E56F8DC6292773603D0D6AABBDD62A11EF721D1542D8
adelgado | 5E884898DA28047151D0E56F8DC6292773603D0D6AABBDD62A11EF721D1542D8
bdavis | 5E884898DA28047151D0E56F8DC6292773603D0D6AABBDD62A11EF721D1542D8
chendrixson | 5E884898DA28047151D0E56F8DC6292773603D0D6AABBDD62A11EF721D1542D8
cpuryear | 5E884898DA28047151D0E56F8DC6292773603D0D6AABBDD62A11EF721D1542D8
cripp | 5E884898DA28047151D0E56F8DC6292773603D0D6AABBDD62A11EF721D1542D8
jsmith | 5E884898DA28047151D0E56F8DC6292773603D0D6AABBDD62A11EF721D1542D8
jpadgett | 5E884898DA28047151D0E56F8DC6292773603D0D6AABBDD62A11EF721D1542D8
jbudd | 5E884898DA28047151D0E56F8DC6292773603D0D6AABBDD62A11EF721D1542D8
ogreene | 5E884898DA28047151D0E56F8DC6292773603D0D6AABBDD62A11EF721D1542D8
hashTest | 28EFB68DCBA507ECD182BEAD31E4E2D159B0F9185861D1EBFE60A12DFB310300
Jun 13, 2020 7:48:16 PM model.MyLogger log
INFO: 2020-06-13T19:48:16.170-05:00[America/Chicago] hashTest Login Success
```

## C4. Source Code

The attached zip “capstone.zip” contains the source code for the application.

## C5. Link to Live Version

The attached zip capstone\_live.zip contains the live version. Once extracted run “Capstone.jar” and use the username “admin” and password “Password1” to gain access to the application. The live application is connected to a cloud-based MySQL instance, so no configuration is necessary for the tester.

## Application Maintenance Guide

### Installation and Debugging of the Application

The purpose of this section is to empower the user to be able to add features or alter the source code for the purposes of bug fixes. This tutorial can be used for Windows, Linux, or Mac.

*Note: The default Global Admin account is 'admin' and the password is 'Password1'. This is generated in step 4 below.*

#### Prerequisites:

- Netbeans 8.2
- Java JDK 8
- Scene Builder (recommended)
- MySQL DBMS

#### Installation:

1. Open Netbeans and navigate to File > Import Project > from Zip.
2. Browse for the Zip file containing the source code (NickAlbers\_Capstone.zip).
3. If the Folder: directory looks agreeable, click Import.
4. In the root directory of the Zip there are 2 SQL scripts that need to be run. The first is ***DDL DB Build.sql*** which builds the database schema and the second is ***Initial DB population.sql*** which populates the database.
5. The final step is to tie it all together by altering the JDBCConn.java class in the database Package. The recommendation is to uncomment the first DB\_URL String line with 127.0.0.1 (if not localhost change to IP of MySQL host machine) and then

commenting the DB\_URL below it.




## User Guide

### Introduction

This guide is designed to give the user a firm understanding on how to login, administer accounts, tools, and facilities, as well as logging calibrations and pulling reports.

### Login Steps


1. Click the Capstone.jar application in the Capstone Folder.
2. Enter your credentials in the Username and Password boxes and click Submit.



3. As of version 1.0 of the application, the users must request an account to be made and password created/reset by either the local administrator from their Facility or a Global Admin.

### Navigating the Main Menu

The main menu is broken into two main components that are used to navigate the application.



## Navigation Bar

The navigation bar resides on the left and is used to traverse the applications many submenus. Clicking on each of the Buttons down the column will trigger the proper table with options on the right.

## Table View

The table view is positioned on the right-hand side of the main menu and contains a quick view of the objects that exist in that category along with some information related to them. Each table view will have 3 options available:

### 1. Create New


This button is located at the top left of the table and will give bring up a new screen to input the necessary information to create a new user, tool, department, etc. Each screen will be slightly different and will be show in the following sections.

### 2. Edit Selected

This button is located at the bottom center of the table view. The first step to using this is to select one of the rows in the table first and then clicking this button. The screen that appears will be nearly identical to the Create New screen with the difference being that the screen is prepopulated with that selected object's information.

### 3. Delete Selected

This button is also located at the bottom of the table view. When selecting on item from the table this button will allow the removal of that object from the list. It will bring up a verification dialog to ensure this action was not by mistake.




## Managing Users

This option is only available to users in the Admin and Global Admin groups.

### 1. New User

The Create New User button brings up a screen that allows the admin to enter a user's Username, User Group, Department, and Password. When the password is entered it is securely hashed with SHA-256 to ensure password security is maintained. Clicking Create will add the new user to the roster on the main menu.



The image shows two side-by-side screenshots of a web application window titled 'Tool Calibration'. The left screenshot is titled 'New User' and contains four input fields: 'User Name' (text), 'User Group' (dropdown menu), 'Department' (dropdown menu), and 'Password' (text). At the bottom are 'Create' and 'Cancel' buttons. The right screenshot is titled 'Edit User' and contains the same four input fields. The 'User Group' dropdown is set to 'Supervisor' and the 'Department' dropdown is set to 'Rail / Set / Canton VPC'. At the bottom are 'Update' and 'Cancel' buttons.

## 2. Edit User


Clicking a user from the list and clicking the Edit Selected will bring up a similar page to the New User. This time the fields will be prepopulated with the selected user's information. The Password field will be blank and will only change the user's password if something is typed in that field.

## Managing User Groups

This option is only available to users in the Admin and Global Admin groups.

### Add/Edit User Group

Within this menu the admin has a list of check boxes that align with sections of the application that can be granted or restricted for the group. In the example below, the Auditor group can only view reports and has no access to edit any data.




The image shows two side-by-side screenshots of a web application window titled 'Tool Calibration'. The left screenshot is titled 'New User Group' and contains a 'Group Name' text field. Below it is a 'Permissions' section with two rows of checkboxes. The first row is labeled 'Alter' and has checkboxes for 'Tools', 'Tool Types', 'Users', 'Dept', 'Facility', and 'Cal Logs'. The second row is labeled 'View' and has a checkbox for 'Reports'. At the bottom are 'Create' and 'Cancel' buttons. The right screenshot is titled 'Edit UserGroup' and contains the same 'Group Name' text field, which is prepopulated with 'Auditor'. The 'Permissions' section is identical to the left screenshot, but the 'Reports' checkbox under the 'View' row is checked. At the bottom are 'Update' and 'Cancel' buttons.

## Managing Departments

This option is only available to users in the Admin and Global Admin groups.

### Add/Edit Department

Within the department screen the admin can assign a name, working shift (1<sup>st</sup>, 2<sup>nd</sup>, 3<sup>rd</sup>), Facility, and the supervisor of that Department.




The image shows two side-by-side screenshots of the 'Tool Calibration' application. The left window is titled 'New Department' and contains the following fields: 'Department Name' (text input), 'Shift' (dropdown menu), 'Facility' (dropdown menu), and 'Supervisor' (dropdown menu). At the bottom are 'Create' and 'Cancel' buttons. The right window is titled 'Edit Department' and contains the same fields, but with pre-filled values: 'Department Name' is 'Accessory', 'Shift' is '1', 'Facility' is 'Carton VPC', and 'Supervisor' is 'cymene'. At the bottom are 'Update' and 'Cancel' buttons.

## Managing Facilities

This option is only available to Global Admins.

### Add/Edit Facilities

This menu is very straight-forward and consists of basic address information for the given Facility.



The image shows two side-by-side screenshots of the 'Tool Calibration' application. The left window is titled 'New Facility' and contains the following fields: 'Facility Name' (text input), 'Street Address' (text input), 'City' (text input), 'State' (text input), and 'Zip' (text input). At the bottom are 'Create' and 'Cancel' buttons. The right window is titled 'Edit Facility' and contains the same fields, but with pre-filled values: 'Facility Name' is 'Seyma VPC', 'Street Address' is '113 Swan', 'City' is 'Seyma', 'State' is 'TN', and 'Zip' is '37129'. At the bottom are 'Update' and 'Cancel' buttons.

## Managing Tool Types

The tool types view is less restrictive than the previous sections and can be altered by the Supervisor group in addition to the Admin groups.

### Add/Edit Tool Types

The tool type screen allows the user to define the testing parameters required on that tool. The most important fields to note here are the following:

- **Variation Type** – Defines whether the measured values of calibration are based on Units of measure (within 1 psi on a tire pressure gauge) or percentage (within 2% of the actual value).
- **Cal Variance** – This field defines the actual tolerance allowed to pass calibration. If percent is used in Variation Type field then this value is represented as a decimal (1 is 100%, 0.05 is 5%).
- **Reference 1,2,3** – These are the 3 known values that the tool is measured against.
- **Units** – Lists the unit of measure that the values will be recorded in.

## Managing Tools

### Add/Edit Tool



The tool menu allows the user to select a Tool Type that's been defined, an owning department, and the tool's serial number as the identifier. This menu also allows the user to take a tool out of service when it is no longer able to maintain calibration. The date will automatically choose the current date if a date is not chosen. The User Signature is autofilled with the currently logged in user.

## Entering Calibration Logs

### Add/Edit Calibration Logs

The Calibration screen gives the user a menu to select the proper tool from. Once selected the Variance and 3 Reference fields populate from the Tool Type of the selected. When the calibrator enters the tested values into the Results boxes a comparison is made. If that test passed it receives a green checkmark, assisting the calibrator improve testing efficiency and reducing chances for error. Once 3 checks are achieved the user can enter the date, flag passed, and submit.

The image shows two side-by-side screenshots of the 'Tool Calibration' application. The left window is titled 'New Calibration' and contains fields for Tool ID, Variance, three Reference values, three Test Result values, Calibration Date, Tested By, and Comments. The right window is titled 'Edit Calibration Log' and shows the same fields with pre-filled data: Tool ID is 'Torque Wrench 1234', Variance is '2.0', References are '50.0', '100.0', and '150.0', Test Results are '50.5', '101.0', and '150.0', Calibration Date is '6/1/2020', and Tested By is 'admin'. Both windows have 'Create' or 'Update' and 'Cancel' buttons at the bottom.

## Reports

To access the Reports menu, select Reports from the Navigation bar. This will bring up a list of options on the left and an open text field on the right. Selecting one of the options on the left will bring up a preview of the report in the text field.

The image shows a screenshot of the 'Report Menu' window. On the left is a navigation bar with buttons: 'Calibration Due', 'Tool List By Department', 'Out of Service Tools', and 'Main Menu'. The main area displays a table titled 'Preview' with the following data:

Type	Serial	Last Cal	Department	Supervisor
1/4" Torque Wrench	1234	2020-05-01	Distribution	chendrixson
Voltmeter	6578	2020-05-01	Accessory	cgreene
3/8" Torque Wrench	36745	2020-04-29	Rail	None
1/4" Torque Wrench	5936	No Record	Distribution	chendrixson

At the bottom right of the window is an 'Export CSV' button.

This information is great if you just need to get a quick look to gain information from the report; however, its usefulness is really limited to just that. If further analysis or report distribution is needed a better solution is to use the Export CSV button at the bottom right. This file can then be opened in a spreadsheet application or e-mailed.